

MODEL MP30 - 1/8 DIN DIGITAL WEIGHT INDICATOR



- DIRECT INTERFACE TO LOAD CELLS (4 X 350 OHM)
- FAST 20 READINGS/SEC UPDATE RATE
- DUAL RANGE INPUT: ± 24 mV OR ± 240 mV
- SELECTABLE 5 VDC OR 10 VDC BRIDGE EXCITATION

- BACKLIGHTED WEIGHT UNITS INDICATOR
- PROGRAMMABLE AUTO-ZERO TRACKING
- TARE AND ZERO FUNCTIONS
- MAX AND MIN READING MEMORY
- PROGRAMMABLE INPUT AND OUTPUT RESPONSE TIMES
- INTEGRATOR/TOTALIZER
- THREE PROGRAMMABLE DIGITAL CONTROL INPUTS
- FOUR SETPOINT ALARM OUTPUTS (W/Plug-in card)
- COMMUNICATION AND BUS CAPABILITIES (W/Plug-in card)
- ANALOG OUTPUT SIGNAL (W/Plug-in card)
- PC SOFTWARE AVAILABLE FOR INDICATOR CONFIGURATION
- NEMA 4X/IP65 SEALED FRONT BEZEL
- UNIVERSAL AC OR 24 V SUPPLY OPTION



GENERAL DESCRIPTION

The MP30 is a high accuracy yet compact digital indicator suitable for simple weighing and control applications. The 5 digit readout employs advanced technology for stable, drift free readout while incorporating features that provide application flexibility now and in the future with field plug-in option cards. Option cards enhance the indicator functions, affording Alarm outputs, Linear DC signal output and two-way Serial Communications.

The weight Indicator has two bipolar input ranges: ± 24 mV and ± 240 mV. The built-in bridge excitation is of low-drift design and is selectable for 5 VDC or 10 VDC output. The indicator can drive 4, 350 ohm load cells. Calibrating the indicator is easy due to the choice of scaling procedures: Either 1) Apply calibration weights to the weighing system or 2) Directly key-in data based upon known load cell calibration data.

The indicator has a simple five button keypad. The key functions are: Weight display select, Parameter Access, Tare In/Out, Acquire Zero, and Print Ticket. Additionally, three of these keys can be programmed for different functionality.

The indicator provides readout selections of Brutto/Gross Weight, the Net weight and the Tare Weight. The Tare Weight can be acquired automatically by a single key-press or via a keypad direct entry.

The indicator also has a means of recording the Max and Min reading, as well as having a Totalizer feature. The totalizer provides either a free running accumulation of total mass flow; or keeps account of total batch weight when adding individual ingredients.

The indicator has four setpoint outputs, implemented on Plug-in cards. The Plug-in cards provide dual FORM-C relays (5 A), quad FORM-A relays (3 A) or either sinking or sourcing quad open collector logic outputs. The setpoint alarms can be configured in modes to suit a variety of control and alarm requirements.

- High and low absolute, high and low deviation and band acting
- Balanced or unbalanced hysteresis
- On and off delay timers

- Auto reset or latching modes
- Reverse phase output and/or panel indicator
- Selection of alternate list of setpoint values
- Tracks gross or net weight



Plug-in cards also facilitate bus communications. These include RS232, RS485 and DeviceNet. Readout values and setpoint alarm values can be controlled through the bus. Additionally, the indicator has features that allow a remote computer to directly control the outputs of the indicator. This is useful during commissioning phases and diagnostic use. With a communication card installed, set-up software allows configuration from a PC. The configuration data can be saved to a file for later recall.

A linear DC output signal is available as a Plug-in card. The card provides either 20 mA or 10 V signals. The output can be scaled independent of the input range. The output can be used as a control or signal retransmission.

- The features of the linear output card are:
- Output tracks either gross or net weight
 - Programmable output update times

Once the indicator has been initially configured, the parameter list may be locked out from further modification in its entirety or only the setpoint values can be made accessible.

The indicator has been specifically designed for harsh industrial environments. With NEMA 4X/IP65 sealed bezel and extensive testing of noise effects to CE requirements, the indicator provides a tough and reliable local readout.



SPECIFICATIONS

- DISPLAY:** 5 digit, 0.56" (14.2 mm) red sunlight readable LEDs, (-19999 to 99999)
- POWER:**
 - 115/230 V Version (MP30/00)
 - AC Power: 85 to 250 VAC, 50/60 Hz, 15 VA
 - Isolation: 2300 Vrms for 1 min. to all inputs and outputs.
 - Working Voltage: 300 V.
 - 24 V Version (MP30/01)
 - DC Power: 11 to 36 VDC, 11 W (derate operating temperature to 40°C if operating <15 VDC and all three plug-in cards are installed)
 - AC Power: 24 VAC, ±10%, 50/60 Hz, 15 VA
 - Isolation: 500 Vrms for 1 min. to all inputs and outputs.
 - Working Voltage: 50 V.
- ANNUNCIATORS:**
 - B/G** - Brutto/gross weight display
 - NET** - Net weight display
 - T** - Tare weight display
 - SP1** - setpoint alarm 1 is active
 - SP2** - setpoint alarm 2 is active
 - SP3** - setpoint alarm 3 is active
 - SP4** - setpoint alarm 4 is active
 - Units Label** - software controlled weight units label backlight
- KEYPAD:** 5 keys
- A/D CONVERTER:** 16 bit resolution
- UPDATE RATES:**
 - A/D conversion rate: 20/readings sec
 - Step response: 200 msec. max. to within 99% of final readout value (digital filter and internal zero correction disabled)**
 - 700 msec. max. (digital filter disabled, internal zero correction enabled)**
 - Display update rate: 1 to 20 updates/sec
 - Setpoint output on/off delay time: 0.0 to 3275.0 sec
 - Analog output update rate: 0.0 to 10.0 sec
 - Max./Min. capture delay time: 0.0 to 3275.0 sec
- DISPLAY MESSAGES:**
 - "OLOL" - Appears when measurement exceeds + signal range.
 - "ULUL" - Appears when measurement exceeds - signal range
 - "..." - Appears when display values exceed + display range.
 - "-..." - Appears when display values exceed - display range.
- CONNECTION TYPE:** 4 or 6 wire bridge
- COMMON MODE RANGE** (w.r.t. input common): 0 to +5 VDC
 - Rejection: 80 db (DC to 120 Hz)
- SENSOR INPUTS:**

Input Range	Accuracy* (18 to 28°C)	Accuracy* (0 to 50°C)	Impedance	Max Continuous Overload	Resolution
±24 mVDC	0.02% of reading +3 µV	0.07% of reading +4 µV	100 Mohm	16 V	1 µV
±240 mVDC	0.02% of reading +30 µV	0.07% of reading +40 µV	100 Mohm	16 V	10 µV

* After 20 minute warm-up. Accuracy is specified in two ways: Accuracy over an 18 to 28°C and 10 to 75% RH environment; and accuracy over a 0 to 50°C and 0 to 85%RH (non-condensing environment). Accuracy over the 0 to 50°C range includes the temperature coefficient effect of the indicator.

** The indicator periodically (every 12 seconds) imposes a 500 msec delay to compensate for internal zero drift. If the delay affects applications where step response is critical, it can be defeated. Set the display update to 20/sec to disable. In this case, add a zero error of 0.2% FS to the 24 mV input range over the 0 to 50°C span.

11. BRIDGE EXCITATION :

Jumper Selectable: 5 VDC @ 65 mA max., ±2%
10 VDC @ 125 mA max., ±2%
Temperature coefficient (ratio metric): 20 ppm/°C max.

12. LOW FREQUENCY NOISE REJECTION:

Normal Mode: > 60 dB @ 50 or 60 Hz ±1%, digital filter off
Common Mode: >100 dB, DC to 120 Hz (w.r.t. earth)

- USER INPUTS (Logic Level):** Three software defined user inputs, jumper selectable for sink/source logic

INPUT STATE	SINKING INPUTS 22 KΩ pull-up to +5 V	SOURCING INPUTS 22 KΩ pull-down
Active	V _{IN} < 0.9 VDC	V _{IN} > 3.6 VDC
Inactive	V _{IN} > 3.6 VDC	V _{IN} < 0.9 VDC

Max. Continuous Input: 30 VDC

Isolation To Sensor Input Common: Not isolated

User Inputs are isolated from all option card terminals.

14. TOTALIZER:

Time Base: second, minute, hour, or day
Time Accuracy: 0.01% typical
Decimal Point: 0 to 0.0000

Scale Factor: 0.001 to 65.000

Low Signal Cut-out: -19,999 to 99,999

Total: 9 digits, display alternates between high order and low order readouts

15. CUSTOM LINEARIZATION:

Data Point Pairs: Selectable from 2 to 12

Display Range: -19,999 to 99,999

Decimal Point: 0 to 0.0000

16. SERIAL COMMUNICATIONS: (RS232 or RS485)

Isolation To Sensor & User Input Commons: 500 Vrms for 1 min.

Working Voltage: 50 V. Not Isolated from all other commons.

Data: 7/8 bits

Baud: 300 to 19200

Parity: no, odd or even

Bus Address: selectable 0 to 99, Max. 32 meters per line (RS485)

Transmit Delay: Selectable for 2 to 50 msec or 50 to 100 msec (RS485)

17. ANALOG OUTPUT :

Types: 0 to 20 mA, 4 to 20 mA or 0 to 10 VDC

Isolation To Sensor & User Input Commons: 500 Vrms for 1 min.

Working Voltage: 50 V. Not Isolated from all other commons.

Accuracy: 0.17% of FS (18 to 28°C); 0.4% of FS (0 to 50°C)

Resolution: 1/3500

Compliance: 10 VDC: 10 KΩ load min.
20 mA: 500 Ω load max.

18. SETPOINT OUTPUT: Two types of field installable cards

Dual Relay Card:

Type: Two FORM-C relays

Isolation To Sensor & User Input Commons: 2000 Vrms for 1 min.

Contact Rating:

One Relay Energized: 5 amps @ 120/240 VAC or 28 VDC (resistive load), 1/8 HP @120 VAC, inductive load

Total current with both relays energized not to exceed 5 amps

Life expectancy: 100K cycles min. at full load rating. External RC snubber extends relay life for operation with inductive loads

Quad Relay Card:

Type: Four FORM-A relays

Isolation To Sensor & User Input Commons: 2300 Vrms for 1 min.

Contact Rating:

One Relay Energized: 3 amps @ 250 VAC or 30 VDC (resistive load), 1/10 HP @120 VAC, inductive load

Total current with all four relays energized not to exceed 4 amps

Life Expectancy: 100K cycles min. at full load rating. External RC snubber extends relay life for operation with inductive loads

19. ENVIRONMENTAL CONDITIONS:

Operating Temperature Range: 0 to 50°C (0 to 45°C with all three plug-in cards installed)

Storage Temperature Range: -40 to 60°C

Operating and Storage Humidity: 0 to 85% max. non-condensing

Altitude: Up to 2000 meters

20. CERTIFICATIONS AND COMPLIANCES:

ELECTROMAGNETIC COMPATIBILITY

Immunity to EN 50082-2

Electrostatic discharge	EN 61000-4-2	Level 3; 8 Kv air
Electromagnetic RF fields	EN 61000-4-3	Level 3; 10 V/m ¹ 80 MHz - 1 GHz
Fast transients (burst)	EN 61000-4-4	Level 4; 2 Kv I/O Level 3; 2 Kv power
RF conducted interference	EN 61000-4-6	Level 3; 10 V/rms 150 KHz - 80 MHz
Simulation of cordless telephones	ENV 50204	Level 3; 10 V/m 900 MHz ± 5 MHz 200 Hz, 50% duty cycle

Emissions to EN 50081-2

RF interference	EN 55011	Enclosure class A Power mains class A
-----------------	----------	--

Notes:

- Self-recoverable loss of performance during EMI disturbance at 10 V/m:*

Measurement error exceeds unit specifications

For operation without loss of performance:

Mount unit in a metal enclosure (Buckeye SM7013-0 or equivalent)

Route power and I/O cables in metal conduit connected to earth ground.

- CONNECTIONS:** High compression cage-clamp terminal block

Wire Strip Length: 0.35" (9 mm)

Wire Gauge Capacity: One 14 AWG solid or Two 18 AWG

- CONSTRUCTION:** This unit is rated for NEMA 4X/IP65 indoor use. IP20 Touch safe. Installation Category II, Pollution Degree 2. One piece bezel/case. Flame resistant. Synthetic rubber keypad. Panel gasket and mounting clip included.

- WEIGHT:** 10.4 oz. (295 g)




Safety Summary

All safety related regulations, local codes and instructions that appear in the manual or on equipment must be observed to ensure personal safety and to prevent damage to either the instrument or equipment connected to it. If equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.

Do not use this unit to directly command motors, valves, or other actuators not equipped with safeguards. To do so can be potentially harmful to persons or equipment in the event of a fault to the unit.

FRONT PANEL

Display
Readout
Indicators



Weight
Units
Overlay

Setpoint
Alarm
Annunciators

KEY FUNCTIONS

TARA KEY FUNCTION

The TARA key selects among the Gross, Net and Tare weight displays. Corresponding panel enunciators illuminate to indicate the selected display. If Tare weight = 0, the indicator prevents selection of Gross and Net weight displays. Within the program menu, this key quits programming and returns to display mode.

PAR KEY FUNCTION

The PAR key allows access to the configuration parameters. The function of this key can be locked.

Within the program menu, this key stores the active parameter and indexes to the next.

During Digital Tare, this key stores the tare weight value keyed in.

T KEY

The T (Tare In/Tare Out) key both acquires and clears the Tare weight value. The function of this key can be changed by setting the F1 function parameter. For data entry, this key is also used to increment a parameter value.

→0← KEY

The →0← key (Zero) re-zeros the Basic and Gross readout displays. The function of this key can be changed by setting the F2 function parameter. For data entry, this key is also used to decrement a parameter value.

⊙ Key

The ⊙ key (Print) causes a Print Ticket output. Prints occur regardless of scale motion. The function of this key can be changed by setting the RST function parameter. For data entry, this key is also used to scroll a parameter value by x1000 factor when held with the Tare and Zero keys.

DISPLAYS

BASIC WEIGHT DISPLAY

The Basic Weight Display provides a direct indicator readout. The display occurs when the Tare Weight = 0.

BRUTTO/GROSS WEIGHT DISPLAY

This Display indicates the Brutto/Gross weight. It is only possible to select this display mode when Tare > 0, otherwise it is locked out by the indicator. "B/G" illuminates for this display mode.

NET WEIGHT DISPLAY

This Display indicates the Net weight. It is only possible to select this display mode when Tare > 0, otherwise it is locked out by the indicator. If after the Tare Weight is set > 0, the Net Display is selected by the indicator. "NET" illuminates for this display mode.

TARE WEIGHT DISPLAY

This Display indicates the Tare weight. When this display is selected, it is possible to directly key-in the Tare Weight value. "T" illuminates for this display mode. It flashes during tare weight key-in entry.

JUMPER LINK FUNCTIONS

The indicator has three jumper links that must be set prior to operation. These are:


• Input Range Select

Select either ± 24 mVDC or ± 240 mVDC range. Select an input range high enough to avoid input signal overload. Program the input range to match jumper selection.



• Bridge Excitation Select

Select either 5 VDC or 10 VDC bridge excitation.

• User Input Source or Sink Select



BASIC CONNECTIONS



Sensor Input Common is NOT isolated from User Input Common.

WEIGHT UNITS OVERLAY


The indicator has a backlighted units indicator that can be customized to the application. The backlight is turned on by programming the “b-L tk” parameter. Overlays are supplied with the indicator. To install an overlay, remove the unit from the case. Select the label and apply it to the label frame, noting that the label must be aligned accurately. Install the label frame to the display board in the alignment holes located on the right side of the display.

PLUG-IN CARDS

The MP30 indicator has provisions for inclusion of three plug-in option cards. Connection data is provided with each card. These cards are:

- Setpoint Outputs
- Analog Outputs
- Communication Option

The plug-in cards can be used in any combination, however, it is only possible to use one type of card from each category. Cards can be installed initially, or at a later date as system needs arise.



WARNING: Disconnect power to the unit before installing plug-in cards. To install a card, depress the side latches at the finger holds and remove the unit from the rear of the case. Insert the card into the appropriate slot and re-install the unit.

INPUTS

The indicator has two input ranges: ± 24 mV DC or ± 240 mV DC. Set the internal jumper link to select the desired range. Select the matching range in programming. Select a range that is high enough to accommodate the bridge output to avoid overload. To allow use of the higher sensitivity 24 mV input range, use 5 V excitation with high output (3 mV/V) bridges. 5 V excitation also reduces bridge power compared to 10 V excitation.

A maximum of four 350 ohm load cells can be driven by the internal bridge excitation voltage.

DEADLOAD COMPENSATION

In some cases, the combined deadload and liveload output may exceed the range of the 24 mV input. To use this range, the output of the bridge can be offset a small amount by applying a fixed resistor across one arm of the bridge. This shifts the electrical output of the bridge to within the operating range of the indicator. A 100 K fixed resistor shifts the bridge output approximately -10 mV (350 ohm bridge, 10 V excitation).

Apply the resistor across +SIG to signal common. Use a metal film resistor with a low temperature coefficient of resistance.

SCALING

The indicator has been factory calibrated on both ranges as a basic millivoltmeter. The basic indicator readout can then be post-scaled to read out in weight units. The indicator provides two ways in which to scale the display:

Key-in: Key in the input and display scaling points using known data.

Apply: Apply the actual input value and key in the corresponding display value. The indicator records the input value applied.

For processes that require linearity compensation, up to 12 scaling points can be used for correction. The indicator interprets the last *dSPn* parameter as the full scale capacity of the system. This determines the number of leading zeros for display. The scaling range is extended up to five digits of resolution with selectable scale division units. 6-digit readouts are afforded by installing a dummy zero unit label.

READ RATE

The display readout, max/min reading, setpoint outputs and analog update have independent update rates. The fastest update rate (20 readings/sec) ensures detection of fast events (such as burst testing, pressure, and peak weight, etc.)

AUTOMATIC ZERO TRACKING

The indicator can be programmed to automatically compensate for zero drift. Drift may be caused by changes in the transducers or electronics, or accumulation of material on weight systems.

Auto-zero tracking operates whenever the readout remains within the tracking band for a period of time equal to the tracking delay time. When these conditions are met, the indicator re-zeroes the readout. After the re-zero operation, the indicator resets and continues to auto-zero track.

The auto-zero tracking band should be set large enough to track normal zero drift, but small enough to not interfere with small process inputs.

For filling operations, the fill rate must exceed the auto-zero tracking rate. This avoids false tracking at the start of the filling operation.

$$\text{Fill Rate} \geq \frac{\text{tracking band}}{\text{tracking time}}$$

Auto-zero tracking is disabled by setting the tracking band parameter = 0.

Note: The Automatic Zero operation is blocked when the total accumulated zero exceeds the value of the Zero Acquisition Range.

Note: The indicator does not have motion detection. Mechanical vibrations coupled to the scale from other machinery may result in false Auto-Zero operations.

DIGITAL FILTER

A unique adaptive input filter is used. Whenever the difference between one reading and the next is less than the filter band value, the input is filtered. When the difference exceeds the filter band value, the input is not filtered. This avoids the usual compromise between using a relative high time constant for good noise rejection and using a low time constant filter for quick step response.

FUNCTION KEYS

The Tare, Zero, and Print keys, in lieu of the standard function, can be programmed for different functions, or no function at all. Additionally, the Tare and Zero keys have second functions. The second function is activated after the primary function if the key is held for 3 seconds.

MAX AND MIN READING DETECTION *

The indicator records the maximum (max) and minimum (min) process inputs. Conditions such as valve activation, sudden change in material flow rate, etc., can result in false peaks which are not reflective of the true maximum and minimum of the process. In this case, Max and Min capture delay times can be used to prevent the detection of false maximums and minimums.

TOTALIZER (integrator) *

The totalizer can be used to integrate a time-input product (such as flow). The totalizer accumulates input readings according to the following relation:

$$\begin{aligned} \text{Total}(n) &= \text{Total}(n-1) + [\text{Input}(n) * (\text{scale factor}/\text{time base})] \\ n &= \text{nth sample instant (seconds)} \\ \text{input} &= \text{input reading (ignore decimal point position)} \\ \text{scale factor} &= 0.001 \text{ to } 65.000 \\ \text{time base: sec} &= 1 \\ &\quad \text{min} = 60 \\ &\quad \text{hour} = 3600 \\ &\quad \text{day} = 86,400 \end{aligned}$$

When the total exceeds 5 digits, the front panel annunciator "T" flashes. In this case, the indicator continues to totalize up to a 9 digit value. The high order 4 digits and the low order 5 digits of the total are displayed alternately. The letter "h" denotes the high order display.

The total decimal point position is independent of the input. A low cut value disables totalization below a set input value. Alarms can be programmed to activate when a set total is reached.

Alternately, the totalizer can also be used to accumulate batch weighing operations. Each time the batch function is executed, the weight is added to the total and then zeroed.

PARAMETER LOCK MODE

A user input can be used to lock the parameter list. When the user input is active, the indicator is in the protected parameter mode, where it is only possible to access the setpoint values and the security code.

It is possible to lock the parameter list without using a user input as a program lock function. In this case, set the security code to a non-zero value. With a non-zero security value set, press the PAR key to view the programmed setpoint values. The security code requires a matching "key" value to gain access to the full parameter list.

BASIC OPERATION

TARE WEIGHT REGISTER

The indicator has a single Tare Weight register. There are two modes in which Tare data is acquired: Pushbutton Tare and Digital Tare.

PUSHBUTTON TARE

Pushbutton Tare is activated by a single key press of the Tare In/Tare Out Key.

Acquire Tare (Tare In):

Tare weight must be cleared, and Basic Weight Displayed.

Place Tare weight on scale.

Allow readout to stabilize.

Press T key.

Indicator acquires the Tare weight with these actions:

If new Tare weight value >0, indicator displays "tARE" and selects Net Weight display.

If new Tare weight < or = 0, indicator rejects Tare weight and displays "notAR".

Clear tare (Tare Out):

Select Gross or Net Weight display.

Tare weight can be either on or off scale.

Press T key to clear Tare weight

Indicator selects Basic Weight display.

DIGITAL TARE

Digital Tare allows a direct entry of the Tare Weight.

Enter Digital Tare:

Select the Tare Weight display.

Enter the Tare Weight using the Tare, Zero and Print keys. In this mode, they take on data entry functions. Use the Tare key as an increment key and the Zero key as a decrement key.

The "T" annunciator flashes to indicate Tare Weight entry.

Press the PAR key to register the Tare weight value. The indicator selects either Net Weight display (new Tare Weight >0) or Basic weight display (new Tare weight = 0).

Press the TARA key to abort the Tare entry mode.

PUSHBUTTON ZERO

Pushbutton Zero is activated by a single key press of the Zero Key.

To Zero:

Select Basic or Gross Weight display.

Allow readout to stabilize

Press 0 key to re-zero the Gross Weight. Meter displays "rESEt".

Note: This operation is blocked when the total accumulated zero exceeds the value of the Zero Acquisition Range.

PRINT TICKET

A ticket print is activated by a single key press of the Print Key.

To Print:

Place weight on scale and allow readout to stabilize.

Press P key.

(Print format is programmable in Module 7-5rL.)

AUTOMATIC AND MANUAL ZERO ACQUISITION

There are two means by which the indicator keeps an accurate zero: Automatic and Manual. The indicator saves the new zero state in an identical way in which the Tare Weight is saved. See Tare Weight Entry for details of operation.

AUTOMATIC ZERO ACQUISITION

In Automatic mode, the indicator automatically re-zeroes when the Gross weight falls within a specified amount of scale divisions of zero (given by the Autozero track band parameter) and remains within this band for a specified amount of time (given by the Autozero track time). The indicator continues to track zero in this fashion until the total accumulated zero offset exceeds the Zero Acquisition Range. When exceeded, Autozero tracking is disabled.

Note: The indicator does not incorporate a means to detect stability. As a result, scale vibration about zero may cause a false Auto-Zero operation.

MANUAL ZERO ACQUISITION

In Manual Zero operation, the Gross weight is zeroed each time the function is executed. The function is activated by a key press or user input transition. If the total accumulated zero offset exceeds the Zero Acquisition Range, the function is disabled. In this case, the indicator must be re-calibrated to the load sensing device, in order to reset the true system zero and hence the accumulated zero offset. The accumulated zero offset itself is reset whenever any of the input scaling parameters are altered.

The indicator displays a brief message **RESET** whenever a zero operation occurs. The indicator displays **00** whenever the total accumulated zero exceeds the value of the Zero Acquisition parameter. In this case, the zero operation is blocked.

“B-GNT” Operating Mode

In the “**b-gnt**” operating mode, the Basic, Gross, Net and Tare Weight can be displayed and controlled. In this mode, indicator functions that pertain to Max and Min reading memory and the Totalizer are disabled. This is the default mode.

“HILOT” Operating Mode

In the “**hilot**” operating mode, the Max, Min and Totalizer indicator functions can be displayed and controlled. In this mode, the Gross, Net and Tare weight displays and control are disabled (Basic display only.). The table lists the correspondence of the display annunciators in this mode.

Annunciator	Readout
B/G	Max reading
NET	Min Reading
T	Totalizer/Integrator

* Only functional in “HILOT” operating mode.

SETPOINT ALARMS

The indicator has two setpoint alarm Plug-in cards. Only one of these cards can be installed at a time. These are:

- Dual relay, FORM-C
- Quad relay, FORM-A

The setpoint alarms can be independently configured for a variety of operating modes. It is also possible to set the alarms to trigger from the totalizer value. Each setpoint alarm can be programmed to trigger from the Brutto/Gross weight or the Net weight. The setpoint alarm figures illustrate the operating modes:

Setpoint Alarm Values

When setpoint alarm is programmed as deviation or band acting, the effective trigger point is offset by SP1. In these modes, SP1 acts as a master setpoint, that the other setpoints track.

An alternate list of setpoint values can be stored and recalled as needed. Select the alternate list with a function key or user input and program the setpoint values. This allows for quick changeover for a new process condition.

Setpoint Alarm Hysteresis and On/Off Time Delay

Depending on the application, hysteresis or On/Off time delays can be used. When the setpoint is a control output, hysteresis is usually used to control the cycle period. Optionally, time delay can also be employed to ensure minimum On/Off times. This is useful to limit the cycling of mechanical control equipment.

On/Off time delays are effective when the setpoint is used as an alarm output. The time delays can be used to prevent false triggering during process transient events, while hysteresis eliminates output chatter at the switch point.

The hysteresis value can be selected to act in the balanced mode or unbalanced mode. In the balanced mode, the hysteresis action is centered about the trigger point, while in the unbalanced mode the hysteresis acts on one side of the trigger point. When the setpoint is a control output, usually balanced hysteresis is used. This tends to center the oscillation around the setpoint value. For alarm applications, usually unbalanced hysteresis is used. This makes the alarm activate precisely at the trigger value.

Setpoint Alarm Output Phase and Panel Annunciator

The output phase (logic) of each setpoint can be reversed. While the front panel indicator follows the output state, it can be programmed to reverse as well; or flash for added emphasis.


OUTPUT	ON CONDITION
RELAY	Energized

Setpoint Alarm Reset Modes, Standby Operation

Each setpoint alarm can be programmed for auto or latching reset modes. Standby operation can be used to prevent the triggering of a low alarm until the process first exceeds the alarm value. This suppresses false alarms during system start-up.

PROGRAMMING MENU

The programming menu of the indicator is accessed by pressing the **PAR** key. The menu is organized into modules, which group together parameters which are related in function. Use the arrow keys to select the module, then press **PAR** to enter the module. The **PAR** key stores the selected parameter and simultaneously indexes to the next parameter. (*Note: Since many parameters are dependent on the scale division setting, it is recommended to scale the display first, then set the other parameters.*)



PARAMETER MODULE 1 - Input Configuration Parameters

DISPLAY	PARAMETER	RANGE AND UNITS	DESCRIPTION/ COMMENTS
rRNGE	Input Range	002u - ±24 mV 02u - ±240 mV	Select the input range Set the input range jumper to match the selection
dECPt	Decimal Point Position	0 00 000 0000 00000	Select scaled decimal point position
rOUNd	Scale Divisions	1 - round by 1 2 - round by 2 5 - round by 5 10 - round by 10 20 - round by 20 50 - round by 50 100 - round by 100	Select scale divisions

DISPLAY	PARAMETER	RANGE AND UNITS	DESCRIPTION/ COMMENTS
FILtR	Filter Setting	00 to 250 seconds	Sets the digital filter time constant. 0 = disabled
bRNd	Filter Enable Band	0 to 250 scale divisions	0 = filter always on Δ = reading - previous reading filter on : Δ < band filter off : Δ > band
PLtS	Scaling Points	2 to 12	Select # of scaling points
StYLE	Scaling Style	KEY - key-in data APLY - apply calibration weights	Select Scaling technique. Procedure resets zero function.
INP x	Input Value for Scaling Point x	- 19999 to 19999	Key-in or apply input value for scaling point x. If applied, press PAR to accept signal. Decimal point follows range selected.
dSP x	Display Value for Scaling Point x	- 19999 to 99999	Key-in display value for scaling point x. Decimal point follows that assigned.

PARAMETER MODULE 2 - External Input and Front Panel Function Key Configuration Parameters

DISPLAY	PARAMETER	RANGE AND UNITS	DESCRIPTION/ COMMENTS
USr-1 USr-2 USr-3	User Input Function	na - no function PL0C - Lock parameter list rEL - Acquire zero	User Input #1, #2, and #3 programming. Active = Lock Active edge = Zero
	** d-rEL	Select net/gross display	Active = Net
	d-Hld	Hold Display	
	R-Hld	Hold all functions	Active = Hold
	Sync	Synchronize meter readings	Release from active = Synchronize
	* bRt	Store batch readings in totalizer	Active edge = Batch
	* d-tot	Select total display	Active = Total
	* r-tot1	Reset totalizer	Active = Reset
	* r-tot2	Reset and enable totalizer	Active = Enable
	* E-tot	enable totalizer	Active = Enable
	* d-h1	Select max display	Active = Max
	* r-h1	Reset, display and enable max reading	Active = Function
	* d-La	Select min display	Active = Min
	* r-La	Reset, display and enable min reading	Active = Function
	* r-HL	Reset max and min	Active = Reset
	d-LEu	Change display intensity level	Settings = 0, 3, 8, 15
	L1St	Select main or alternate setpoint list	Active = Alternate main = Lad-R alternate = Lad-b
	r-1	Reset setpoint 1	Maintained Reset
	r-2	Reset setpoint 2	Active = Reset

DISPLAY	PARAMETER	RANGE AND UNITS	DESCRIPTION/ COMMENTS
		r-3 - Reset setpoint 3 r-4 - Reset setpoint 4 r-34 - Reset setpoint 34 r-234 - Reset setpoint 234 r-RL - Reset all setpoints	Maintained Reset Active = Reset
		Prnt - Print Request	Maintained Action Active = Print
	** tRE	Acquire/Clear tare	Active edge = acquire or clear tare
F1 F2 rSt Sc-F1 Sc-F2	Tare Key Zero Key Print Key Second F1 Second F2	na - No function rEL - Acquire zero d-rEL - No function * bRt - batch totalizer * r-tot - reset totalizer * r-h1 - reset max * r-La - reset min * r-HL - reset max and min L1St - Select main or alternate setpoint list	Keypad function programming. These keys can be programmed to different functions. Function is executed when key is pressed. Hold key for 3 seconds for second function. main = Lad-R alternate = Lad-b
		r-1 - Reset setpoint 1 r-2 - Reset setpoint 2 r-3 - Reset setpoint 3 r-4 - Reset setpoint 4 r-34 - Reset setpoint 34 r-234 - Reset setpoint 234 r-RL - Reset all setpoints	Momentary Reset
		Prnt - Print Request	Momentary Action
	** tRE	Acquire/Clear tare	

* No function in "B-GNT" mode.
** No function in "HILOT" mode.

PARAMETER MODULE 3 - Parameter and Display Lock-out Configuration Parameters

DISPLAY	PARAMETER	RANGE AND UNITS	DESCRIPTION/ COMMENTS
b-b	Brutto/Gross Display (B-GNT mode) or Max/Min Display (HILOT mode)	L00 - lockout rEd - display readout	Enables either Gross display or Max/min display depending on the operating mode.
tArE	Tare Display (B-GNT mode) or Totalizer Display (HILOT mode)	L00 - lockout rEd - display readout ENt - read and enter value	Enables either Tare display or Totalizer display depending on the operating mode.
SP-1	Setpoint 1	L00 - lockout	Protected Parameter Mode Options
SP-2	Setpoint 2	rEd - read only	
SP-3	Setpoint 3	ENt - read and enter value	
SP-4	Setpoint 4		
Code	Security Code	0 to 250	Security Code; code ≠ 0 parameters are locked. 222 = universal unlock

* - The values entered for these parameters are multiplied by the value entered for Scale Divisions in Module1 to obtain the final values.

PARAMETER MODULE 4 - Secondary Function Configuration Parameters

DISPLAY	PARAMETER	RANGE AND UNITS	DESCRIPTION/ COMMENTS
OPER	Operating Mode	b-bNt : Gross, Net, and Tare functions HILOt : Max, Min, and Totalizer functions	B-GNT is the default mode.
*Hi-t	Max Capture Delay Time	00 to 32750 sec	Sets time delay for capturing new max/min values. Helps to avoid false captures.
*Lo-t	Min Capture Delay Time		
dSP-t	Display Update Rate	1, 2, 5, 10, 20 updates/second	Affects display rate only. 20/sec disables zero correction (See Specs)
0-rNG	Zero Acquisition Range *	0 to 4095 scale divisions	Allowable zero range limited to this value. 0 = ¼ scale division 4095 = no limit
Rt-t	Auto-zero Tracking Delay Time	0 to 250 second	Set delay time long enough to avoid false re-zeros 0 = OFF
Rt-b	Auto-zero Tracking Band *	1 to 4095 scale divisions	Tracking on: reading ≤ band Tracking off: reading = 0 reading > band
b-Lt	Units Label Backlight	0N - Backlight on OFF - Backlight off	Install label
dSP-F	Display Format	LERd0 - Leading zero LERdb - Leading blank	Sets leading zero or leading blank Display format

* For "HILOT" operating mode only.

PARAMETER MODULE 5 - Totalizer Configuration Parameters

DISPLAY	PARAMETER	RANGE AND UNITS	DESCRIPTION/ COMMENTS
dECPt	Totalizer Decimal Point Position	0 00 000 0000 00000	Independent of input scaling.
tBASE	Totalizer Time Base	SEC _in hour day	Set the time base of the totalizer. _in = minutes

DISPLAY	PARAMETER	RANGE AND UNITS	DESCRIPTION/ COMMENTS
SCFAC	Totalizer Scale Factor	0000 to 65000	
Locut	Low Cut Value	-19999 to 99999	Input < locut disables totalizer
P-UP	Power Up Reset	00 - do not reset buffer r5t - reset buffer	Resets totalizer buffer at indicator power-up

PARAMETER MODULE 6 - Setpoint Parameters

DISPLAY	PARAMETER	RANGE AND UNITS	DESCRIPTION/ COMMENTS
SPSEL	Select Setpoint		Select setpoint for configuration
Rct-n	Action for Setpoint	OFF - setpoint is disabled Rb-Ht - absolute high, balanced hysteresis Rb-L0 - absolute low, balanced hysteresis RU-Ht - absolute high, unbalanced hysteresis RU-L0 - absolute low, unbalanced hysteresis *dE-Ht - deviation high, unbalanced hysteresis *dE-L0 - deviation low, unbalanced hysteresis *bRRd - band outside, unbalanced hysteresis **t0tLa - Lower totalizer absolute high, unbalanced **t0tHi - Upper totalizer absolute high, unbalanced	Select operating action for setpoint See Figures for operation Deviation and Band operation is relative to SP1. *Not available for SP1 ** Totalizer has 9 digit capacity. Select to trigger on the upper or lower portion of the number. Only applies to "HILOT" mode.

DISPLAY	PARAMETER	RANGE AND UNITS	DESCRIPTION/ COMMENTS
SP-n	Setpoint Value	-19999 to 99999	Main or alternate, as selected
tRb-n	Trigger Source	b-b - Brutto/Gross weight NEt - Net weight	For b-bNt mode only.
HYS-n	Hysteresis	1 to 65000	
tON-n	On Time Delay	00 to 32750 sec	
tOF-n	Off Time Delay		
out-n	Output Logic	nor - Normal rEu - Reversed	
rSt-n	Reset Action	RUt0 - Automatic Reset LRLt1 - Latch w/immediate reset LRLt2 - Latch w/delayed reset	See Reset Mode Figure
Stb-n	Standby Operation	00 - Disable standby YES - Enable standby	Power-up standby operation.
LIt-n	Output Panel Light	OFF - Always off nor - On when output on rEu - Reverse from nor FLASH - Flashes when output is on	

PARAMETER MODULE 7 - Serial Communications Parameters

DISPLAY	PARAMETER	RANGE AND UNITS	DESCRIPTION/ COMMENTS
bRd	Baud Rate	300 600 1200 2400 4800 9600 19200	Set baud rate to match other equipment. Set to 9600 for PC configuration software.
dRtR	Number of Data Bits	7 8	8 = No parity
PRr	Parity Bit	0dd EVEN 00	Possible Combinations: 8, N, 1 7, O, 1 7, E, 1 7, N, 2
Rddr	Node Address	0 to 99	Unique address for each indicator. Set to 0 for PC configuration software.
Rbrv	Abbreviated Output	00 - ID characters printed yE5 - ID characters suppressed	Select full or abbreviated transmission

DISPLAY	PARAMETER	RANGE AND UNITS	DESCRIPTION/ COMMENTS
UN It	Line Print Units Suffix	00 - None G - Grams kg - Kilograms lb - Pounds oz - Ounces t - Tons 0 - False zero 0G - Zero and grams 0kg - Zero and kilograms 0lb - Zero and pounds 0oz - Zero and ounces	Select weight units for line print.
0PE	Print Options	yE5 - Enter sub-menu 00 - Disables parameter **6r055 - Brutto/Gross weight **tRrE - Tare weight REt - Net weight *t0t - Totalizer values *H IL0 - Max and Min values SPRt - Setpoint values	Sub-menu to select parameters for inclusion on print ticket.

* - Not in "B-GNT" mode
** - Not in "HILOT" mode.

PARAMETER MODULE 8 - Analog Output Parameters

DISPLAY	PARAMETER	RANGE AND UNITS	DESCRIPTION/ COMMENTS
tYPE	Select Analog Output Type	0-20 - 0 to 20 mA 4-20 - 4 to 20 mA 0-10 - 0 to 10 V	
RS IN	Output Source Assignment	b-b - Brutto/Gross weight *H I - Max reading *L0 - Min reading *t0t - Totalizer value REt - Net weight	Select source of linear output signal. If totalizer, scaling limited to lower 5 digits.

DISPLAY	PARAMETER	RANGE AND UNITS	DESCRIPTION/ COMMENTS
RR-L0	Display Scale Value Low		Low = 0 mA/ 4 mA/ 0 V High = 20 mA/ 10 V
RR-H I	Display Scale Value High	- 9999 to 99999	For reverse acting, reverse scale high and scale low
udt	Update Time	00 to 100 sec	0.0 = Instant updates

* - Not in "B-GNT" mode

PARAMETER MODULE 9 - Factory Service Function Parameters

DISPLAY	PARAMETER	RANGE AND UNITS	DESCRIPTION/ COMMENTS
d-LEu	Display Intensity Level	0 to 15	0 = dimmest 15 = brightest
Code	Factory Service Access Code	48 - Calibration 55 - Restore Factory Defaults	All other codes result in exit.

The basic indicator is factory calibrated for both the high and low mV input ranges. In the application, the user scales the basic mV to units of weight (Input Scaling). To re-calibrate the complete weighing system (load cells and indicator together) with calibration weights, execution of the Input Scaling procedure suffices. It generally is not necessary to re-calibrate the input of basic indicator.

In the case of using known data from load cells where the mV readings are directly keyed-in, then the input can be re-calibrated. Calibration reference accuracy of 0.01% in the 20 and 200 mV ranges is required.

Calibration of the indicator is divided into two parts: the Input Calibration and Analog Output calibration.

Input Calibration

Note: This procedure affects the basic indicator mV input calibration. As a result, it may require the indicator to be rescaled using calibration weights.

From the **ERL** display, select the input or output for calibration:

002 20 mV input (Set 20 mV range jumper)

02 200 mV input (Set 200 mV range jumper)

DISPLAY	ACTION
000u or 00u	Apply 0 mV between + and - SIG inputs, with -SIG tied to common, wait 10 seconds, press PAR
002u or 02u	Apply +20 or +200 mV to + and - SIG inputs, with -SIG tied to common, wait 10 seconds, press PAR

Output Calibration

The Analog Output signal is re-calibrated by setting the end points of each range. These end points correlate with Analog Output scaling parameters AN-LO and AN-HI. Calibration meter accuracy of 0.05% in the 10 VDC and 20 mA ranges is required.

DISPLAY	ACTION
00 R	Use Tare and Zero keys to set mA output to 0.00 mA. Press PAR to accept.
40 R	Use Tare and Zero keys to set mA output to 4.00 mA. Press PAR to accept.
200 R	Use Tare and Zero keys to set mA output to 20.00 mA. Press PAR to accept.
00u	Use Tare and Zero keys to set volt output to 0.00 V. Press PAR to accept.
100u	Use Tare and Zero keys to set volt output to 10.00 V. Press PAR to accept.

PARAMETER VALUE CHART Code _____

1- INP - Input Parameters

DISPLAY	PARAMETER	FACTORY SETTING	USER SETTING
rRNGE	INPUT RANGE	0020	_____
dECPt	DISPLAY RESOLUTION	00000	_____
rOUNd	SCALE DIVISIONS	00001	_____
FILtR	FILTER SETTING	00000	_____
bRNd	FILTER ENABLE BAND	00002	_____
PtS	SCALING POINTS	2	_____
StYLE	SCALING STYLE	YFY	_____
INP 1	INPUT VALUE 1	00000	_____
dSP 1	DISPLAY VALUE 1	00000	_____
INP 2	INPUT VALUE 2	20000	_____
dSP 2	DISPLAY VALUE 2	10000	_____
INP 3	INPUT VALUE 3	0000	_____
dSP 3	DISPLAY VALUE 3	000	_____
INP 4	INPUT VALUE 4	0000	_____
dSP 4	DISPLAY VALUE 4	000	_____
INP 5	INPUT VALUE 5	0000	_____
dSP 5	DISPLAY VALUE 5	000	_____
INP 6	INPUT VALUE 6	0000	_____
dSP 6	DISPLAY VALUE 6	000	_____
INP 7	INPUT VALUE 7	0000	_____
dSP 7	DISPLAY VALUE 7	000	_____
INP 8	INPUT VALUE 8	0000	_____
dSP 8	DISPLAY VALUE 8	000	_____
INP 9	INPUT VALUE 9	0000	_____
dSP 9	DISPLAY VALUE 9	000	_____
INP 10	INPUT VALUE 10	0000	_____
dSP 10	DISPLAY VALUE 10	000	_____
INP 11	INPUT VALUE 11	0000	_____
dSP 11	DISPLAY VALUE 11	000	_____
INP 12	INPUT VALUE 12	0000	_____
dSP 12	DISPLAY VALUE 12	000	_____

2- Fnc - External Input and Function Key Parameters

DISPLAY	PARAMETER	FACTORY SETTING	USER SETTING
USr-1	USER INPUT 1	NO	_____
USr-2	USER INPUT 2	NO	_____
USr-3	USER INPUT 3	NO	_____
F1	TARE KEY FUNCTION	tRr	_____
F2	ZERO KEY FUNCTION	rEL	_____
rSt	PRINT KEY FUNCTION	Pr InK	_____
Sc-F1	2nd TARE KEY FUNCTION	NO	_____
Sc-F2	2nd ZERO KEY FUNCTION	NO	_____

3- LOC - Parameter Lockouts

DISPLAY	PARAMETER	FACTORY SETTING	USER SETTING
B-6	BRUTTO/GROSS DISPLAY	rEd	_____
tRrE	TARE DISPLAY	EnK	_____
SP-1	SETPOINT 1	LOC	_____
SP-2	SETPOINT 2	LOC	_____
SP-3	SETPOINT 3	LOC	_____
SP-4	SETPOINT 4	LOC	_____
Code	SECURITY CODE	00000	_____

4- SEC - Secondary Function Parameters

DISPLAY	PARAMETER	FACTORY SETTING	USER SETTING
OPER	OPERATING MODE	b-6Nt	_____
*M1-t	MAX CAPTURE DELAY TIME	00000	_____
*L0-t	MIN CAPTURE DELAY TIME	00000	_____
dSP-t	DISPLAY UPDATE TIME	2	_____
0-rNG	ZERO ACQUISITION RANGE	00060	_____
Rt-t	AUTO-ZERO TRACKING DELAY TIME	00000	_____
Rt-b	AUTO-ZERO TRACKING BAND	00001	_____
b-L It	UNITS LABEL LIGHT	ON	_____
dSP-F	DISPLAY FORMAT	LErD0	_____

5- Tot - Totalizer Parameters

DISPLAY	PARAMETER	FACTORY SETTING	USER SETTING
dECPt	TOTALIZER DECIMAL POINT	00000	_____
tBASE	TOTALIZER TIME BASE	1 ⁿ	_____
SCFAC	TOTALIZER SCALE FACTOR	0.0000	_____
Locut	TOTALIZER LOW CUT VALUE	-199.99	_____
P-UP	TOTALIZER POWER-UP RESET	NO	_____

7- SerL - Serial Communication Parameters

DISPLAY	PARAMETER	FACTORY SETTING	USER SETTING
bRUD	BAUD RATE	9600	_____
dRtR	WORD LENGTH	8	_____
PRr	PARITY	NO	_____
Raddr	ADDRESS	00000	_____
Rbru	ABBREVIATED	NO	_____
UN It	PRINT UNITS	Y6	_____
BrGSS	PRINT BRUTTO/GROSS	YES	_____
tRrE	PRINT TARE WEIGHT	YES	_____
NEt	PRINT NET WEIGHT	YES	_____
*tOt	PRINT TOTAL	NO	_____
*M IL0	PRINT MAX and MIN	NO	_____
SPNt	PRINT SETPOINT VALUES	NO	_____

8- Out - Analog Output Parameters

DISPLAY	PARAMETER	FACTORY SETTING	USER SETTING
tYPE	ANALOG TYPE	4-20	_____
AS In	ANALOG ASSIGNMENT	b-6	_____
AN-L0	ANALOG LOW SCALE VALUE	00000	_____
AN-H1	ANALOG HIGH SCALE VALUE	10000	_____
udt	UPDATE TIME	00000	_____

9- FCS - Factory Setting Parameters

DISPLAY	PARAMETER	FACTORY SETTING	USER SETTING
d-LEu	DISPLAY INTENSITY LEVEL	3	_____

* - Appears only in "HILOT" operating mode.

5-5P1 - Setpoint Parameters

DISPLAY	PARAMETER	FACTORY SETTING	USER SETTING	DISPLAY	PARAMETER	FACTORY SETTING	USER SETTING
RC1-1	ACTION FOR SETPOINT	OFF	_____	RC1-3	ACTION FOR SETPOINT	OFF	_____
SP-1	SETPOINT VALUE (main)	00000	_____	SP-3	SETPOINT VALUE (main)	00000	_____
	SETPOINT VALUE (alternate)*	00000	_____		SETPOINT VALUE (alternate)*	00000	_____
Src-1	SETPOINT SOURCE	b-6	_____	Src-3	SETPOINT SOURCE	b-6	_____
HY5-1	SETPOINT HYSTERESIS	00002	_____	HY5-3	SETPOINT HYSTERESIS	00002	_____
TON-1	ON TIME DELAY	00000	_____	TON-3	ON TIME DELAY	00000	_____
TOF-1	OFF TIME DELAY	00000	_____	TOF-3	OFF TIME DELAY	00000	_____
out-1	OUTPUT LOGIC	nor	_____	out-3	OUTPUT LOGIC	nor	_____
rSt-1	RESET ACTION	RULto	_____	rSt-3	RESET ACTION	RULto	_____
Stb-1	STANDBY OPERATION	NO	_____	Stb-3	STANDBY OPERATION	NO	_____
L1k-1	OUTPUT PANEL LIGHT	nor	_____	L1k-3	OUTPUT PANEL LIGHT	nor	_____

DISPLAY	PARAMETER	FACTORY SETTING	USER SETTING	DISPLAY	PARAMETER	FACTORY SETTING	USER SETTING
RC1-2	ACTION FOR SETPOINT	OFF	_____	RC1-4	ACTION FOR SETPOINT	OFF	_____
SP-2	SETPOINT VALUE (main)	00000	_____	SP-4	SETPOINT VALUE (main)	00000	_____
	SETPOINT VALUE (alternate)*	00000	_____		SETPOINT VALUE (alternate)*	00000	_____
Src-2	SETPOINT SOURCE	b-6	_____	Src-4	SETPOINT SOURCE	b-6	_____
HY5-2	SETPOINT HYSTERESIS	00002	_____	HY5-4	SETPOINT HYSTERESIS	00002	_____
TON-2	ON TIME DELAY	00000	_____	TON-4	ON TIME DELAY	00000	_____
TOF-2	OFF TIME DELAY	00000	_____	TOF-4	OFF TIME DELAY	00000	_____
out-2	OUTPUT LOGIC	nor	_____	out-4	OUTPUT LOGIC	nor	_____
rSt-2	RESET ACTION	RULto	_____	rSt-4	RESET ACTION	RULto	_____
Stb-2	STANDBY OPERATION	NO	_____	Stb-4	STANDBY OPERATION	NO	_____
L1k-2	OUTPUT PANEL LIGHT	nor	_____	L1k-4	OUTPUT PANEL LIGHT	nor	_____

* Select alternate list to program these values.

TROUBLESHOOTING

As part of the start-up procedure, the indicator performs a series of internal self tests. If one or more of the diagnostic tests fails, indicator operation is disabled and an error message is displayed. Press the TARA key to acknowledge the error.

Refer to the error table below for the cause and remedy for the fault detected. For further technical assistance, contact technical support at the appropriate company numbers listed.

Error Code	Problem	Remarks
Err 1	Internal hardware fault	A fault of the microprocessor and/or the input circuit has been detected. Return indicator for repair.
Err 2	Parameter list memory fault	One or more of set-up parameters has changed value due to possible electrical glitch or loss of power during parameter save operation. (during "End" display) Verify all set-up parameters, exit parameter set-up mode and cycle power to indicator to clear error. If error remains, return indicator for repair.
Err 3	Calibration memory fault	Verify calibration accuracy of indicator. If out of tolerance, re-calibrate the indicator. Otherwise, to clear error, enter and exit parameter set-up mode and cycle power to indicator. If error remains, return indicator for repair.
Err 4	Analog output calibration memory fault	Verify calibration accuracy of analog output. To clear error, enter and exit parameter set-up mode and cycle power to indicator. If error remains, replace analog output card.
Err 5	Defective keypad	The indicator has detected one of the keypad switches is defective. Inspect keypad for signs of damage or sticking. Cycle power to indicator to clear error. If error remains, return indicator for repair.

Installation Environment

The indicator should be installed in a location that does not exceed the maximum operating temperature and provides good air circulation. The minimum vertical clearance to allow proper ventilation is 1". Placing the unit near devices that generate excessive heat should be avoided. Be sure to keep it away from heat sources (ovens, furnaces, etc.), away from direct contact with caustic vapors, oils, steams, or any other process by-products that may affect proper operation.

Continuous exposure to direct sunlight may accelerate the aging process of the bezel. The bezel should be cleaned only with a soft cloth and neutral soap product. Do NOT use solvents.

Do not use tools of any kind (screwdrivers, pens, pencils, etc.) to operate the keypad of the unit.

EMC GUIDELINES

The indicator has been designed and tested to meet the requirements of EMC Directive 89/336/EEC. However, successful installations depend upon several factors. These include cable routing, termination of cable shields, associated equipment, etc.

Installation

The indicator meets NEMA 4X/IP65 requirements for indoor use when properly installed. The unit is intended to be mounted into an enclosed panel. Prepare the panel cutout to the dimensions shown in the Dimensions drawing. Remove the panel latch and cardboard sleeve from the unit and discard the cardboard sleeve. Slide the panel gasket over the rear of the unit to the back of the bezel. The unit should be installed fully assembled. Insert the unit into the panel cutout. While holding the unit in place, push the panel latch over the rear of the unit so that the tabs of the panel latch engage in the slots on the case. The panel latch should be engaged in the forward most slot possible. To achieve a proper seal, tighten the latch screws evenly until the unit is snug in the panel (Torque to approximately 7 in-lbs [79N-cm]). Do not over-tighten the screws.

APPLICATION - Tank Level Monitor w/Alarm and Loss-of-Weight Fill

This application uses the MP30 indicator to monitor the weight of a liquid storage tank. The indicator is connected directly to 4 - 350 ohm load cells, using the internal 10 VDC excitation source. The average sensitivity of the load cells are 2.1 mV/V. This yields a full scale output of approximately 21 mV which is within the maximum input of 24 mV of the indicator's low range.

Calibration of the indicator can consist of any two arbitrary scale points. In this application, the low scaling point was determined by metering in 1,000 liters of liquid into the tank and the high scaling point, 10,000 liters. For this application, the indicator scaling values are:




Parameter	Value
INP 1	1.728 mV
dSP 1	1,000 ltr
INP 2	20.750 mV
dSP 2	10,000 ltr

The indicator registers the output of the load cells at these points and corresponds them to the readout display values.

A four output relay setpoint card is installed. 120 VAC Two of the relays provide HI and LO level alarm outputs. These alarms are programmed to trigger on the Gross liquid weight of the tank.

The remaining alarm outputs are used for a simple loss-of-weight filling application. One is programmed as a low-acting alarm, triggering on the Net liquid weight. Each filling operation is started with a Tare Out / Tare In sequence. This opens the filling valve and when the target setpoint is reached, the valve is shut off. The valve remains off until a tare operation is repeated, thereby restarting the filling operation. The fourth output is connected in series with the fill output to disable filling during the interval of the Tare Out and Tare In operation.

A Linear DC Output plug-in option card is also installed. This card provides either 10 V or 20 mA conditioned and scaled output for remote sensing and logging of the tank level.



MODEL INFORMATION

Product	Product Name	Product Number
Weight Indicator (85 - 250VAC Power)	MP30/00	9408-800-30001
Weight Indicator (24V Power)	MP30/01	9408-800-30011
Dual Relay Option Card	MP30/11	9408-800-30111
Quad Relay Option Card	MP30/10	9408-800-30101
Linear Output Option Card	MP30/20	9408-800-30201
RS232 Comm Option Card	MP30/31	9408-800-30311
RS485 Comm Option Card	MP30/32	9408-800-30321
DeviceNet Comm Option Card	MP30/40	9408-800-30401
PC Set-up Software	MP30/50	9408-800-30501